

# CONSOLE INSTALLATION INSTRUCTIONS.

CANTERBURY HEATERS SALES CODE CONSCANT-B

ISSUE:G. DATED:20/06/12

PART No: F3078

## KIT COMPONENTS:

TOP PANEL	1 OFF
LHS PANEL	1 OFF
RHS PANEL	1 OFF
TOP BRACE	1 OFF
SPACER BRACKET	2 OFF
WALL BRACKET	1 OFF
EXTENDED FLUE SPIGOT	1 OFF
SELF TAPPING SCREWS	14 OFF
PLAIN WASHERS	6 OFF
SEALING STRIP.	2.2 M
FLUE REDUCER	1 OFF

YOUR CANNON CONSOLE KIT IS DESIGNED FOR EASY INSTALLATION WITH YOUR CANNON HEATER BY AN AUTHORIZED SERVICE PERSON ONLY. THE HEATER IS FOR INSTALLATION INTO AN **AGA** APPROVED FLUE SYSTEM ONLY.

PLEASE NOTE, THE REAR OF **THE HEATER MUST BE 50 mm FROM ANY COMBUSTIBLE SURFACE**. THIS IS ACHIEVED WITH THE USE OF THE PROVIDED SPACER BRACKETS. THE HEATER MAY BE INSTALLED ON A TIMBER FLOOR. THE HEATER IS **NOT TO BE INSTALLED ON TOP OF CARPET** OR SIMILAR FLOOR COVERING.

PLEASE FOLLOW THE FOLLOWING INSTALLATION INSTRUCTIONS AND FIGURES 1 TO 7 (ON THE BACK OF THE PAGE) CAREFULLY. REMOVE THE FRONT FASCIA, REFER TO HEATER INSTALLATION INSTRUCTIONS.

- STEP 1.** FIT TOP BRACE TO THE TOP OF THE HEATER BY REMOVING THE TWO SELF TAPPING SCREW INDICATED AND THEN REFITTING THEM WITH THE TOP BRACE IN PLACE. **SEE FIG 1.**
- STEP 2.** TO PROVIDE THE CORRECT SPACING OF 50 mm BETWEEN THE BACK OF THE HEATER AND THE WALL, FIT A SPACER BRACKET TO EITHER SIDE OF THE HEATER BY REMOVING THE APPROPRIATE SCREWS AND THEN RE FITTING THEM WITH THE SPACER BRACKET IN PLACE. **SEE FIG 2.**
- STEP 3.** FIT THE FLUE REDUCER AND EXTENDED FLUE SPIGOT BY REMOVING THE FLUE SPIGOT OR FLUE COVER FITTED TO THE HEATER USING THE SELF TAPPING SCREWS REMOVED FROM THE HEATER. **SEE FIG 3.**
- STEP 4.** ASSEMBLE THE TWO SIDE PANELS TO THE TOP PANEL USING FOUR SELF TAPPING SCREWS PROVIDED, TAKING CARE NOT TO OVER TIGHTEN THE SCREWS. FIT THE SEALING STRIP TO THE BACK EDGE OF THE PANELS. **SEE FIG 4.**
- STEP 5.** TO INSTALL THE WALL BRACKET, MEASURE NOMINATED HEIGHT FROM THE INSTALLING SURFACE AND MARK A HORIZONTAL LINE. USING THE LINE AS A GUIDE, SCREW THE WALL BRACKET TO THE WALL USING TWO OR THREE SCREWS. PLEASE NOTE, THE SCREWS ARE NOT PROVIDED FROM THIS PURPOSE. **SEE FIG 5.**
- STEP 6.** PUT THE HEATER INTO ITS FINAL POSITION AND ANCHOR WITH TWO SCREWS IN EACH OF THE SPACER BRACKETS. ENSURE THAT THE SPACER BRACKETS ARE HARD UP AGAINST THE WALL. **SEE FIG 6.**
- STEP 7.** CONNECT THE GAS TO THE HEATER AND TEST FOR INTEGRITY. REFER TO HEATER INSTALLATION INSTRUCTIONS.
- STEP 8.** LOWER THE ASSEMBLED CONSOLE OVER THE HEATER AND ENGAGE ONTO THE WALL BRACKET AND INTO THE TABS ON THE SPACER BRACKET. FIT THE REMAINDER OF THE SELF TAPPING WITH THE PLAIN WASHERS AS INDICATED. **SEE FIG 7.**
- STEP 9.** TO COMPLETE THE INSTALLATION, FIT THE FRONT FASCIA AND BASE PANEL OF THE HEATER AS YOU WOULD NORMALLY. REFER TO HEATER INSTALLATION INSTRUCTIONS.

SHOULD ANY ASSISTANCE BE REQUIRED OR FOR MORE INFORMATION CONTACT YOUR CANNON DEALER.

# CONSOLE INSTALLATION INSTRUCTIONS.

